

# T-Mobile Hotspot Instructions

Please charge your WIFI hotspot by plugging it in.

Press the button on the front of the device to turn it on.

You will see a welcome message

Press the power button twice to see the WiFi Name

Press the power button one more time to see the WiFi password.

Use this WIFI name and Password to login to WIFI.

## How do you connect a school issued Chromebook to wifi?

**A:** The Chromebook wifi settings are found at the lower right hand of screen. Click on the wifi drop down to see a list of available wifi.

Find the wifi you want to connect to, click on it and provide the required password.

