

**65 tapaa parantaa ja muuttaa lauluääntäsi,
+/- 12 transponointi, myös kesken esityksen,
oman esityksen äänitysmahdollisuus
studiotasolla.**

Duet Harmony

Standard Harmony

Easy Harmony

Light Harmony

Studio Singers

Quartet Harmony

Big Harmony

Big Acapella

Big Choir

Vocoder Schlager

Standard Duet

Standard Trio

Standard Quartet

Studio Vocals

Jazz Quartet

Studio Vocals

Jazzy Quartet

Schlager Trio

Destiny Pop

Vocal Doubler

Vocoder Mono

Vocoder VH

Rock & Roll

Tempo Cross

Heavy Voice

Telephone Choir

Like the80s

Gramophone

Poker Phaser

Detune Voice

Perfect Fourth

Sing C Major Scale

Ballad Choir

Church Choir

Gregorian Choir

Gospel Choir

Cosmic Choir

Alpen Girls

Country Rock

R & B Diva

Closed Pop Chicks

Queen of Pop

Bob to Mary

Mary to Bob

Flanging Vocals

Jazzy Singers

Quartet on Stage

Delayed Harmony

Kid's Choir

Chorus Choir

Bohemian Vocoder

Robot Voice

Chordal XG

Detune XG

Chromatic XG

Vocoder XG

Thru

Monster Pad

Digi Stack

Reflecting

Monster FX

Phat Stack

Uni VCO

JP Saw

Pulse Wawe 10

Pulse Wawe 25

Digi Wawe

Fat Saw

Simple Saw

Sync Saw

Strong Detune