



Remove the push pins holding the light on , there are 4 push pins. Then disconnect the plug that goes to the light .





Remove the 4 screws holding the heat shield on .



Remove the screws holding the light to the main bracket .



Screw the new light into the bracket , and
reinstall the light bracket onto the machine.

stock



AFTERMRKET



Now for the wiring , just follow the diagram (for machines without turn singles just cap that wire off so there no chance of water getting up the wire)

[illegible]