

## Maintenance Information

### Cabinets:

Cabinets should be kept clear of excessive dust, debris, and moisture. Do not block the doorway.

### Alarms:

The alarm system requires an included 9-volt alkaline battery. The battery lifespan is estimated at 2 years. To check the battery, make sure the alarm key is turned to the ON position, then open the cabinet door. The alarm will clearly sound if the battery remains functional. If the alarm does not sound, or the sound is diminished or altered, replace the alarm battery with a new 9-volt alkaline battery. Battery replacement is accomplished through the battery compartment on the bottom of the red alarm housing.