

This document will list the current prices to repair parts of the student chromebooks.

Current Chromebook Replacement Parts Prices

Display- \$70
Keyboard- \$25
Touchpad- \$28
Palmrest with keyboard and touchpad- \$50
Charger- \$30
Battery- \$45
Battery cable- \$15
Top cover- \$35
Bottom cover- \$25
LCD bezel- \$25
Hinges- \$15
LCD video cable- \$20
Camera- \$25
Speakers- \$10
6th-8th Carrying case- \$45
9th-12th Bumper case- \$45
Entire replacement device- \$300

Prices are subject to change as the supplier changes their prices.

Students must pay to replace the broken parts before the chromebook can be repaired. A student may check out a loaner device (if available) while waiting for their chromebook to be repaired.