## ITS TechDocs

# SCC Booth Ferris South (Combined): Directions for Use

Last Revised 11-12-20

#### **General Directions**

- Press the touch screen, on the wall in the middle of Booth Ferris near the window. A message comes up "Are you sure you want to start the system in combined mode?" Yes or No. Select Yes.
- Press the Sources button on the touch screen.
- 3. Choose your source:

HDMI VGA

North Bluray South Bluray

Once a source is selected, the screens and projectors for North and South will activate.

- 4. To control the volume, press Volume ▲ ▼on the right side of the touch screen. Above the Volume ▲ is a Program / Speech button. Toggle between Program and Speech by pressing the button. Program controls the audio from a Source selection, Speech controls the audio from the wireless mics. The Mute button mutes all audio.
- Press the Video Mute button to hide the projected image.
  N.B. Do NOT use Video Mute to shut down, you will burn up the projector.
- 6. Press the **Power** button to completely shut down the system when finished.

### To view a laptop computer

- 1. Attach an HDMI or VGA cable to the jacks located below the touch screen.
- 2. Press **HDMI or VGA** source on the touch screen.
- 3. Control your laptop via its own controls.

### To view a Blu-Ray or DVD disc

- 1. Press North Bluray or South Bluray source on the touch screen.
- Insert your disc into the appropriate Blu-ray player.
- 3. Control the video via the touch screen control panel.

### Microphone Use

- 1. Obtain a wireless microphone from the SCC staff.
- Turn it on.
- 3. Press **Program** on the touch screen. It will change to **Speech**.
- 4. Control the mic volume with the **Volume** extstyle extstyle

5. Press **Speech** again to return to volume control of **Program** (regular use).

### **Final Shutdown**

- 1. Eject all Blu-ray Discs, DVDs, etc.
- 2. Press the **Power** button on the touch screen.
- 3. "Are you sure you want to exit and shut the system down?" Press "Yes".
- 4. The projectors will cool down and shut off automatically. Screens will retract.
- 5. Return any mics or cables to the SCC staff.

\*For Assistance: Ask the SCC student manager at the front desk or contact the SCC Building Manager - 717-358-**4397**