ITS TechDocs

Goethean 207 Classroom: Directions for Use

Last Revised 8-22-22

General Directions

- 1. Press the **ON** button on the push-button controls on the podium. It will light up.
- 2. The projector will beep and turn on automatically.
- 3. Choose a source on the push-button controls. Press the button. It will light up.

HDMI USB-C BLU-RAY MAC

4. Control the volume with the **Volume** knob.

To Display the Room PC

- 1. Press the **Mac** source.
- 2. Press the Power button on the right rear of the computer (if necessary, to turn it on).
- 3. Log in to the Room PC with your NetID and password.

To Display a Laptop

- 1. Press the Source you desire: HDMI or USB-C.
- 2. Attach the appropriate cable to your laptop or device.

To Display a Blu-ray or DVD disc

- 1. Press the **BLU-RAY** Source.
- 3. Press the **Open/Close △** button again to close the tray.
- 4. Use the remote to control playback.

Final Shutdown

- 1. Remove any DVD or Blu-Ray discs.
- 2. Remove any USB-memory sticks.
- 3. Press and hold the **OFF** button on the A/V box. It will remain lit. You will hear the projector beep twice as it turns off.

For Assistance: Call the ITS Help Desk: 717-358-6789