LUBRICATION CHART - EUROFOX 2K AND 3K		
Ser	Description	Lubricant
2. 1	Tail wheel bearing	Grease
2. 2		
2. 3	Wing lower strut mounting bolts	0i1/ACF 50
2. 4	Door hinges	0i1
2.5	Door locks and cables	0i1
2.6	Flapperon bearings on wings	Silicon oil
2. 7	Flapperon bearing on turtle deck	Silicon oil
2.8	Control stick blocks	Silicon oil
2. 9	Rudder pedal bearings	Silicon oil
2. 10	Rudder and elevator hinges	0i1
2. 11	Rudder cable ends	ACF560 rear/Grease cockpit
		end
2. 12	Trim tab hinges and cables	0i1
2. 13	Throttle cable	0i1
2. 14	Oil flap cable and hinges	0i1
2. 15	Heater cable and flap	0i1
2. 16	Elevator control rod end bearing	0i1
2. 17	Pedal centring mechanism	Grease
2. 18		
2. 19		
2. 20		
2. 21		
2. 22	Fuel cap seals	Vaseline
2. 23	Wheel brake assemblies	Copper slip
2. 24	Prop. Hub rear face and bolts/threads	ACF 50/oil
2. 25	Spar to wing rose joints	0i1
2. 26	Wing-fold rear upper pivot bolts and nuts	0i1
2. 27	Cowling top camlocks	ACF 50
2. 28	Turtle deck camlocks	ACF 50
2. 29	General; all exposed metal	0i1
	Nose wheel suspension block pivot and stays	0i1
	Nose wheel pivot blocks	Grease
	Control rod ends (rose joints)	0i1