

COMPLETE GUIDE TO UNLOCK iCloud WITH iTOOLAB UNLOCKGO iOS

1. Download Software (Free)

Visit the official iToolab website and download the latest version of the UnlockGo iOS software. Make sure you download it from the official website to avoid viruses.



Official Download Link:


https://itoolab.com/unlock-iphone/?srsId=AfmBOooiyB9P9yphnPeaiiDSk2oJTkl6ZeywwPVBibiiayymkcQuNr_x

Note: This software is free to download and install. You'll only need to pay later to activate the unlock feature.

License Options (Price):


- 1 Device Plan \$19.95 For 1 iPhone
- 1 Month Plan \$35.95 For 5 devices, valid for 1 month
- 1 Year Plan \$39.95 For 5 devices, valid for 1 year
- Lifetime Plan \$49.95 For 5 devices, valid for life

Recommended: Get the Lifetime Plan (\$49.95) because it's a one-time payment and can be used on other devices in the future.



2. Install the Software

- After installation, open the software, a registration window will appear.
- Click Buy Now, select a package, and complete the payment.
- Check your email for the registration code.
- Enter the code in the registration window and click Register.
- The software is ready to use.



Register



UnlockGo

The version you are using is unregistered.
Please purchase a license or enter the
registration information if you already have
one.

Licensed Email:

Registration Code:

[Buy Now](#) [Free Trial](#) [Register](#)

3. Steps to Unlock iPhone


Preparation:

- Prepare an original USB cable.
- Make sure your iPhone has sufficient battery (>50%).
- Close any heavy applications on your computer.

Steps:


Step 1: Select the Unlock Menu

- Open UnlockGo on your computer.
- On the main page, select the "Unlock iCloud Activation Lock" option.
- Click "Start" to begin.



Step 2: Connect your iPhone


- Connect your iPhone to your computer using a USB cable.
- The program will automatically detect your device.
- Ensure a stable connection and do not unplug the cable during the process.



Step 3: Unlock Process

- Click the "Start" or "Remove Now" button.

- The tool will begin removing the iCloud Activation Lock.
- During the process, your iPhone will restart several times automatically this is normal.
- Wait a few minutes for the process to complete (usually 5-10 minutes).



Step 4: Finish & Verify

- Once the process is complete, the screen will show "Successfully Removed."
- The iPhone will restart and return to the initial setup page.
- You can set it up like a new iPhone.
- Log in with your new Apple ID for verification.
- Test functionality: Make sure you can open the App Store, download apps, and check for cellular signal.

Important Note:

- After unlocking, the iPhone can be restarted or reset without returning to the lock screen.
- Do not set a screen passcode for the time being (specifically for certain models).
- Money-back guarantee if failure occurs (as per iToolab policy).