GOBRAILLE SETUP GUIDE

Welcome to the GoBraille Setup Guide. This Guide will walk you through installing and setting your Irie GoBraille device with your Irie braille embosser.

In the GoBraille box you will find:

- 1 GoBraille unit
- 1 GoBraille power adapter



Once you have your GoBraille and power adapter out of the box, plug the power adapter into the micro USB port on the right-hand side of the of the unit. Then plug your GoBraille power adapter into a wall outlet.



Next, plug your Irie AT embosser's USB cord into one of the four USB ports on the back of the GoBraille.



Once your GoBraille is connected to your embosser and powered on the GoBraille will transmit its own wifi network that you can connect to, to finish the GoBraille setup. Using a computer with wifi capabilities or a mobile device such as a smartphone or tablet, connect to the wifi network called GoBraille.



Once Connected to the GoBraille wifi network, open a web browser on your device and enter https://gobraille into the address field, then press enter or go. Once you do, a web interface for the GoBraille will appear.



Once on the GoBraille web interface, select the System tab. Then under the Wireless LAN Configuration section, choose Connect to another Network. Then using the Available Networks dropdown, select the wifi network you would like to connect the GoBraille to. Enter the wifi password, and then press apply.

WARRNING: When the GoBraille is connected to, or typing to connect to a wifi network, the GoBraille network will no longer be available. Be careful to ensure that the wifi password is correct when typing it in. If the password is wrong or mistyped the GoBraille will not be able to connect to the network, and will have to be reset in order to try again.



Once the GoBraille connects to your existing wifi network, you should notice that you are no longer connected to the GoBraille wifi network, and that it is no longer available. Reconnect your device to your existing wifi network.

Your GoBraille is now connected and ready to use. For mobile devices, the GoBraille will now make your embosser show as an air print perter whenever you go to print from a mobile application. For computers, it is recommended to install the embosser like a regular printer using the driver. To do this connect to the same wifi as the GoBraille on either a PC or mobile device, then open your web browser and type https://gobraille into the address bar. This will open the GoBraille landing page. Select the System tab, then locate the IPv4 Address.



You can then use this IP address to install a copy of the embosser on your PC. To do this, go to Devices and Printers on your PC, then select Add Printer. Then follow the steps to add a printer using TCP/IP and follow the prompts. Your embosser will then be installed on the PC sending the print information to the GoBraille over wifi.

For more detail or additional setup information, please see the GoBraille User Guide here.