SMART Board Important Settings

Click **Settings** at the bottom left corner of the SMART board:

- Save whiteboard files to Lumio so teachers can access them online. [Click here to learn more about Lumio.]
    - Files Library > Under WHITEBOARD STORAGE > press Default Whiteboard Location > Select My Files Saved to Lumio

- Under Files, teachers will have Google Drive as a quick access point:
    - Files Library > Allow Google Drive integration in Files Library - turn ON

- Use your finger to write on the SMART board:
    - SMART Whiteboard > Enable Write or Draw with your Finger (Finger Inking)

- Prompt the teacher before a device automatically shares to the board:
    - Screen Share > Require Permission >Turn ON

- Customize the SMART board wallpaper:
    - Wallpaper > select an image or add an image that was saved on a USB.

- Write on anything displayed on the SMART board:
    - Annotation > Enable Annotation Layers > Turn on

- Hide passwords when typing them on the board:
    - Security > Make password visible > turn off

- Create a shortcut under Favorites on the homepage so teachers can easily access the Whiteboard app.
    - (Not in Settings) Tap Files > On the Whiteboard tile, toggle on the Star in the top right corner.

- Disable the sensor so the board does not turn when someone walks by it (6000 model only - model without an eraser):
    - Press the Menu button on the back of the board or the three lines button on the front. Navigate to Setup > Proximity off