Model3Mat and ModelYMat

Installation Instructions



Thank you for your purchase of a Model3Mat or ModelYMat. It is cut precisely to fit your trunk and made from a light weight but highly wear resistant carpeting that should protect your trunk for years to come. This is made from a non-woven automotive carpet material that will not fray or unravel. The base is made of a rubberized material that will hold it in place. It is waterproof and washable. If it becomes dirty, you can just hose it off and allow it to dry in the sun. Hanging it over a chair will help it dry faster.

To install your new Model3Mat or ModelYMat

1. Remove any items from the trunk.

2. Place the mat in the trunk

3. To position it precisely, fold the edge that contacts the rear seats back about 6” to make it easier to move it about. Position it so the two sides lie at the edges of the trunk rails or sides, and the rear edge is just at the end of the carpeted portion of the trunk floor.

4. Fold the seat edge of the mat down and tuck it gently into the gap behind the rear seats.

5. If you need to modify your mat, you can cut freely with scissors, but for a straight and accurate cut line, mark the line to be cut on both ends of the cut, remove the mat from the trunk, and place it flat on a hard surface, and use a straight edge and razor to cut it cleanly.