
Menu
Edit
Favorites
Extras
System
Help
SAP Easy Access
Other menu
Create role
Assign users
Documentation
Favorites
SAP Menu
Office
Cross-Application Components
Logistics
Accounting
Human Resources
Information Systems
Tools
WebClient UI Framework
SAP Plant Maintenance
Activation of Task List
Copy from Notification to Order
SESSION_MANAGER
zmetdc00
OVR


Implementation Guide
Edit
Goto
Additional Information
Utilities
System
Help
Display IMG
Existing BC Sets
BC Sets for Activity
Structure
Indicate Order Types for Refurbishment
Order Types and Investment Managemer
Configure Number Ranges
Assign Order Types to Maintenance Plant
Assign Inspection Types to Maintenance/
Define Default Value for Planning Indicato
Create Default Value Profiles for External
Define Access Sequence for Determining
Create Default Value Profiles for General
Default Values for Task List Data and Profile Assignments
Settlement Rule: Define Time and Creation of Distribution Rule
Define Proposed Reference Time for Technical Completion
Define Transfer of Project or Investment Program
Define Relevant Fields for Assignment of IM Program
Assign IM Assignment Key to Order Types
Define Default Order Types for Maintenance Items
Define Notification and Order Integration
Control Key
Maintenance Activity Type
Costs at Operation Level
Costing Data for Maintenance and Service Orders
Define Change Documents, Collective Purchase Requisition, MRP relevance
Set Workflow for Orders
Menu path to switch on/off TaskList copy from Notification to Order
IMG -> PM/CS -> Maint.Service Processing -> Maint.Service Orders -> Functions and Settings for Order Types
SAP
SPRO
zmetdc00
OVR


System
Help
SAP
De-activate Task List copy
from Notification to Order
S000
zmetdc00
INS

Table View Edit Goto Selection Utilities System Help

Change View "Maintain notification data in the order header":

New Entries

Or...	Notifctn	Long Text	Enh. ObjectList
AD01	☐	☐	Assignment of Operations to Object List Entries
AD02	☑	☐	Assignment of Operations to Object List Entries
AD03	☐	☐	Assignment of Operations to Object List Entries
FP01	☐	☐	Assignment of Operations to Object List Entries
FP02	☐	☐	Assignment of Operations to Object List Entries
NLM2	☐	☐	Assignment of Operations to Object List Entries Inactive
PAM	☐	☐	Assignment of Operations to Object List Entries Inactive
PM01	☐	☑	Assignment of Operations to Object List Entries Inactive
PM02	☐	☑	
PM03	☐	☑	
PM04	☐	☑	
PM05	☑	☑	
PM06	☐	☑	Assignment of Operations to Object List Entries Inactive
PM07	☐	☑	Assignment of Operations to Object List Entries Inactive
PM08	☐	☑	Assignment of Operations to Object List Entries Inactive
PM09	☐	☐	Assignment of Operations to Object List Entries Inactive
PMOC	☐	☑	3 Assignment of Operations to All Object List Entries Act...
PMPS	☐	☐	3 Assignment of Operations to All Object List Entries Act...
PMXX	☐	☑	Assignment of Operations to Object List Entries Inactive
RM02	☐	☐	Assignment of Operations to Object List Entries Inactive
SM01	☐	☑	3 Assignment of Operations to All Object List Entries Act...

Assignment of Operations to Object List Entries Inactive
1 Assignment of Operations to Maint. Plan Notifications Active
2 Assignment of Operations to All Notifications Active
3 Assignment of Operations to All Object List Entries Active

Current setting for Order Type PM01 is BLANK (Assignment of Operations to Object List not allowed) which includes not just Notification but EQ and FL from the Object List ...

Data was saved

SPRO zmetdc00 OVR


General task list
Edit
Goto
Operation
Extras
Environment
System
Help
Create General Task List: Operation Overview
Internal
External
Task List
Group PM15
Counter 1
Group PM15
Grp.Countr 1
General Operation Overview
Op... SOp Work ctr Plnt Ctrl Operation Description LT VI Work Un. No. Duration Un. C Pct Int. distr
0010 MECHANIK 1000 PM01 task 1 1 H
0020 MECHANIK 1000 PM01 task 2 1 H
0030 MECHANIK 1000 PM01 task 3 1 H
0040 MECHANIK 1000 PM01 task 4 1 H
0050 MECHANIK 1000 PM01 task 5 1 H
0060 MECHANIK 1000 PM01
0070 MECHANIK 1000 PM01
0080 MECHANIK 1000 PM01
0090 MECHANIK 1000 PM01
0100 MECHANIK 1000 PM01
0110 MECHANIK 1000 PM01
0120 MECHANIK 1000 PM01
0130 MECHANIK 1000 PM01
Components
Rel
PRT
SPack.
Insp.Char
Entry 1 / 5
IA05
zmetdc00
OVR


Maintenance notification
Edit
Goto
Extras
Environment
System
Help
Change PM Notification: Maintenance request
Partner
CET
Notification
10001732
M1
Corrective
Notific. Status
OSNO
Order
Notification
System availability
Location data
Scheduling overview
Task List
Items
Tasks
Activities
Task list
Pln Group
GrpCr
Task list description
A / PM15 / 1
Task List is assigned to
Notification Type M1
Notification 10001732
IW22
zmetdc00
OVR


Maintenance notification
Edit
Goto
Extras
Environment
System
Help
Change PM Notification: Maintenance request
Partner
CET
Notification
10001732
M1
Corrective
Notific. Status
OSNO
Order
Notification
System availability
Create
cation data
Scheduling overview
Task List
Items
Tasks
Activities
Task list
Pln Group
GrpCr
Task list description
A / PM15 / 1
Convert Notification to MO
IW22
zmetdc00
OVR


Maintenance notification
Edit
Goto
Extras
Environment
System
Help
Change PM Notification: Maintenance request
Partner
CET
Notification
10001732
M1
Corrective
Notific. Status
OSNO
Order
Notification
System availability
Location data
List
Items
Tasks
Activities
Task list
Pln Group
A / PM15
Create Order
Order Type
PM01
Planning plant
1000
Business Area
1000
Main work center
MECHANIK / 1000
Mechanical maintenance
User Order Type
PM01
IW22
zmetdc00
OVR


Order Edit Goto Extras Environment System Help
Create Maintenance Order : Operation Overview
CET
Order PM01 %00000000001 Corrective
Sys.Status CRTD MANC
HeaderData Operations Components Costs Partner Objects Additional Data Location Planning Control
Op... SOp Work ctr Plant Co... StTextK S.. Operation short text LT VI S... Actual work
0010 MECHANIK 1000 PM01 Corrective
0020 MECHANIK 1000 PM01
0030 MECHANIK 1000 PM01
0040 MECHANIK 1000 PM01
0050 MECHANIK 1000 PM01
0060 MECHANIK 1000 PM01
0070 MECHANIK 1000 PM01
0080 MECHANIK 1000 PM01
0090 MECHANIK 1000 PM01
0100 MECHANIK 1000 PM01
Operations from Task List did not copied to the MO
IW22 zmetdc00 OVR


Order
Edit
Goto
Extras
Environment
System
Help
Task List Selection
Sales data
Contract Selection
Paging Ctrl+F7
Reference object
Assembly operation
Suborders
Cost reports
Documents for Order
Settings
Direct entry
To reference object
General task lists for assembly
General task lists for object structure
General task lists
Display task lists
Create Mai
Order PM01 %00000
Sys.Status CRTD MANC
HeaderData
Operat
Partner
Objects
Additional Data
Location
Planning
Control
Op... SOp Work ctr Plant Co... StTextk S.. Operation short text LT VI S... Actual work
0010 MECHANIK 1000 PM01 Corrective
0020 MECHANIK 1000 PM01
0030 MECHANIK 1000 PM01
0040 MECHANIK 1000 PM01
0050
0060
0070
0080
0090
0100
Information
No task lists are included in the order
No Task List was included in the Order
IW22
zmetdc00
OVR


System
Help
SAP
Activate Task List copy from Notification to Order
S000
zmetdc00
INS


Table View Edit Goto Selection Utilities System Help
Change View "Maintain notification data in the order header": Overview
New Entries
Or... Notifctn Long Text Enh. ObjectList
AD01 Assignment of Operations to Object List Entries Ina
AD02 Assignment of Operations to Object List Entries Ina
AD03 Assignment of Operations to Object List Entries Ina
FP01 Assignment of Operations to Object List Entries Ina
FP02 Assignment of Operations to Object List Entries Inactive
NLM2 Assignment of Operations to Object List Entries Inactive
PAM Assignment of Operations to Object List Entries Inactive
PM01 3 Assignment of Operations to All Object List Entries Activ
PM02
PM03
PM04
PM05
PM06 Assignment of Operations to Object List Entries Inactive
PM07 Assignment of Operations to Object List Entries Inactive
PM08 Assignment of Operations to Object List Entries Inactive
PM09 Assignment of Operations to Object List Entries Inactive
PMOC 3 Assignment of Operations to All Object List Entries Act
PMPS 3 Assignment of Operations to All Object List Entries Act...
PMXX Assignment of Operations to Object List Entries Inactive
RM02 Assignment of Operations to Object List Entries Inactive
SM01 3 Assignment of Operations to All Object List Entries Act...
Assignment of Operations to Object List Entries Inactive
1 Assignment of Operations to Maint. Plan Notifications Active
2 Assignment of Operations to All Notifications Active
3 Assignment of Operations to All Object List Entries Active
Note I set to "3" (for all objects in Object List ie: FL,EQ, Notification etc)
Or at least set to "2" which will recognize the Notification Task List to the Order
Data already saved
SPRO zmetdc00 OVR


Maintenance notification
Edit
Goto
Extras
Environment
System
Help
Change PM Notification: Maintenance request
Partner
CET
Notification
10001732
M1
Corrective
Notific. Status
OSNO
Order
Notification
System availability
Create
tion data
Scheduling overview
Task List
Items
Tasks
Activities
Task list
Pln Group
GrpCr
Task list description
A / PM15 / 1
We return to the Notification to convert Notification to Order again.
IW22
zmetdc00
OVR


Maintenance notification
Edit
Goto
Extras
Environment
System
Help
Change PM Notification: Maintenance request
Partner
CET
Notification
10001732
M1
Corrective
Notific. Status
OSNO
Order
Notification
System availability
Location data
Scheduling overview
Task List
Items
Tasks
Activities
Task list
Pln Group
GrpCr
Task list description
A / PM15 / 1
Ensure Order Type PM01
Create Order
Order Type
PM01
Planning plant
1000
Business Area
1000
Main work center
MECHANIK / 1000
Mechanical maintenance
IW22
zmetdc00
OVR


Order Edit Goto Extras Environment System Help
Create Maintenance Order : Operation Overview
CET
Order PM01 %00000000001 Corrective
Sys.Status CRTD MANC
Note, Task List Operations copied to the MO
HeaderData Operations Components Costs Partner Objects Additional Control
Op... SOp Work ctr Plant Co... StTextK S.. Operation sh... LT VI S... Actual work Work Un N... Du
0010 MECHANIK 1000 PM01 task 1 0 1 H
0020 MECHANIK 1000 PM01 task 2 0 1 H
0030 MECHANIK 1000 PM01 task 3 0 1 H
0040 MECHANIK 1000 PM01 task 4 0 1 H
0050 MECHANIK 1000 PM01 task 5 0 1 H
0060 MECHANIK 1000 PM01 0.0 HR
0070 MECHANIK 1000 PM01 0.0 HR
0080 MECHANIK 1000 PM01 0.0 HR
0090 MECHANIK 1000 PM01 0.0 HR
0100 MECHANIK 1000 PM01 0.0 HR
IW22 zmetdc00 OVR


Order
Edit
Goto
Extras
Environment
System
Help
Task List Selection
Sales data
Contract Selection
Paging Ctrl+F7
Reference object
Assembly operation
Suborders
Cost reports
Documents for Order
Settings
Direct entry
To reference object
General task lists for assembly
General task lists for object structure
General task lists
Display task lists
Create Mai
Order PM01 %00000
Sys.Status CRTD MANC
HeaderData
Operat
Partner
Objects
Additional D
Control
Check which Task List
Op... SOp Work ctr Plant Co... StTextK S.. Operation sh... LT VI S... Un N... Du
0010 MECHANIK 1000 PM01 task 1 1 H
0020 MECHANIK 1000 PM01 task 2 0 1 H
0030 MECHANIK 1000 PM01 task 3 0 1 H
0040 MECHANIK 1000 PM01 task 4 0 1 H
0050 MECHANIK 1000 PM01 task 5 0 1 H
0060 MECHANIK 1000 PM01 0.0 HR
0070 MECHANIK 1000 PM01 0.0 HR
0080 MECHANIK 1000 PM01 0.0 HR
0090 MECHANIK 1000 PM01 0.0 HR
0100 MECHANIK 1000 PM01 0.0 HR
IW22
zmetdc00
OVR


Order Edit Goto Extras Environment System Help
Create Maintenance Order : Operation Overview
Overview of Included Task Lists
Task List
Group 15 Ctr 1
List of task lists
T... Group GrC Task list description Equipment Functional Location
PM15 1
Control
Un N... Du
1H
0070 MECHANIK 1000 PM01
0080 MECHANIK 1000 PM01
0090 MECHANIK 1000 PM01
0100 MECHANIK 1000 PM01
Notification 10001732 M1 Corrective
Notific. Status NOPR ORAS
Order 816020
Notification System availability Location data
Task list
Pln Group GrpCr Task list description
A / PM15 / 1
SAP
IW22 zmetdc00 OVR