

MONARCH

Command

Summary

Version 1.1

Note: If using Computer braille, you need to add Space with commands using Enter or Backspace.

General

Home (Main Menu): Space with Dots 1-2-3-4-5-6 or Home button (circle-shaped button on the front of the device)

Activate Selected item: Enter (Dot 8) or point with one finger and double press Action button

Escape or Back: Space with E or Back button (triangle-shaped button on the front of the device)

Accessibility Volume up: Enter with Dot 4

Accessibility Volume down: Enter with Dot 1

Music volume up: Enter with Dot 5

Music volume down: Enter with Dot 2

Increase speech rate: Enter with Dot 6

Decrease speech rate: Enter with Dot 3

Increase Braille line spacing: Zoom In (+) Button

Decrease Braille line spacing: Zoom out (-) Button

Force dynamic refresh: Long press the Action button

Open KeySoft Options: Space with O

Jump to any item in a list: Type the first letter of the item or app

Activate notification shade: Enter with N

Open Android settings: Enter with Q

Stop speech: BackSpace with Enter

Repeat: Space with R

Running apps: Recent apps button (square button on the front of the device)

Context menu: Space with M or press and hold Recent apps button (square button on the front of the device)

Contextual help: Space with H

System information: Space with I

Toggle language profile: Enter with L

Turn screen reader and accessibility on / off: Press and hold Volume up and Volume down buttons for 3 seconds

Toggle speech on/off: Backspace with Enter with S

Toggle Braille grade: Backspace with G

Toggle from Computer Braille to Literary Braille: backspace with space with G

Battery status: Enter with P

Time: Enter with T

Date: Enter with D

Manually create bug report: Backspace with Enter with R

Focus cursor to top line: Enter with F (In lists, it brings the item with focus to the top of the braille display. In edit texts, it brings the line containing the cursor to the top of the braille display).

General navigation

Previous item: D-pad Up, Backspace or Space with Dot 1

Next item: D-pad down, Space or Space with Dot 4

Pan up and down: Up or Down Panning key

Go to top: Space with Dots 1-2-3

Go to bottom: Space with Dots 4-5-6

Reading

Previous character: D-pad left or Space with Dot 3

Current character: Space with Dots 3-6

Next character: D-pad right or Space with Dot 6

Previous word: Space with Dot 2

Current word: Space with Dots 2-5

Next word: Space with Dot 5

Previous line: Space with Dot 1

Current line: Space with Dots 1-4

Next line: Space with Dot 4

Move cursor at current position to previous line: D-pad up

Move cursor at current position to next line: D-pad down

Previous paragraph: Space with Dots 2-3

Current paragraph: Space with Dots 2-3-5-6

Next paragraph: Space with Dots 5-6

Jump to the beginning of a line or sentence (Home): Enter with Dots 1-3

Jump to the end of a line or sentence (End): Enter with Dots 4-6

Jump to the top of an area: Space with Dots 1-2-3

Jump to the bottom of an area: Space with Dots 4-5-6

Read all: Space with G

Stop reading: Backspace with Enter

Editing

Delete previous word: Backspace with Dot 2

Delete current word: Backspace with Dots 2-5

Delete previous character: Backspace (Dot 7)

Move insertion point to start of text field document: Space with Dots 1-2-3

Move insertion point to end of text field document: Space with Dots 4-5-6

Delete from cursor to the end of the line: Backspace with C

Delete from cursor to the end of the document: Backspace with Dots 4-5-6

Start/Stop selection: Enter with S
Select all : Enter with Dots 1-2-3-4-5-6
Copy: Backspace with Y
Cut: Backspace with X
Paste: Backspace with V

KeyWord Commands

Save: Space with S
Save as: Backspace with S
Create file: Backspace with N
Open file: Backspace with O
Switch documents: Space with Dots 1-2-5-6
File info: Space with I
Find : Space with F
Find next: Space with N
Find previous: Space with P
Replace: Backspace with F
Toggle Reading mode : Space with X
Launch KeyMath: Backspace with M
Equation Editor: Enter with M
Preview print document: Enter with V
Spell check: Space with Dots 1-6
Tab: Backspace with T
Insert page break: Backspace with P
Align left: Backspace with L
Align center: Enter with C
Align right: Enter with R
Align justify: Enter with J
Bold: Enter with B
Italic: Enter with I
Underline: Enter with U

Formatting details: Space with Dots 3-5

Braille Editor : KeyBrf Commands

Save: Space with S

Save as: Backspace with S

Find : Space with F

Find next: Space with N

Find previous: Space with P

Toggle Reading mode : Space with X

Victor Reader

Table of contents: Space with T

Go to page: Enter with G

Next page: Enter with O

Previous page: Enter with Dots 2-4-6

Where am I: Space with Dots 1-5-6

Book Info: Space with I

Next Heading: H

Previous Heading: Backspace with Enter with H

Next heading level 1 to 6: Dots 1 to 6

Previous heading level 1 to 6: Add backspace with Enter to the level choice

Tactile Viewer Commands

Pan left: Left or right D-pad left

Pan right: Left or right D-pad right

Pan Up: Left or right D-pad up

Pan Down: Left or right D-pad down

Zoom In: Zoom In (+) Button or Point and double press Action button

Zoom out: Zoom out (-) Button

Top left: Space with Dot 1

Center left: Space with Dot 2

Bottom left: Space with Dot 3

Top right: Space with Dot 4

Center right: Space with Dot 5

Bottom right: Space with Dot 6

Top center: Space with C

Center: Space with Dots 2-5

Bottom center: Space with Dots 3-6

Rotate the display: Space with R
Switch to overview mode: Zoom out (-)
Switch to standard mode: Zoom In (+)
File info: Space with I
Invert Braille: Space with Dots 3-5
Show less details: Space with Dot 1-3
Show more details: Space with J
Apply OTSU Threshold: Backspace with O
Apply Gaussian Filter: Space with G
Apply Dilation Filter: Space with D
Undo Last Filter: Space with Z
Add Bookmark: Backspace with M
Jump To Bookmark: Backspace with J
Go to page: Enter with G
Next Page: Enter with O
Previous Page: Enter with Dots 2-4-6
Index page: Enter with I

TGIL Library

Search: Space with F
Save file locally: Space with S

File Manager

New Folder: Space with N
Rename file or folder: Backspace with R
Mark/Unmark file or folder: Backspace with L
Mark all files or folders: Enter with Dots 1-2-3-4-5-6

Delete file or folder: Backspace with Dots 2-3-5-6

Copy to: Backspace with Y

Cut file/Move to: Backspace with X

Search : Space with F

Drive Selection: Space with D

Perform current action: Backspace with A

File info: Space with I

Math: KeyMath

New Expression: Space with N

Insert symbols in an expression: Backspace with Dots 3-5

Modify expression : Enter (On expression)

Graph viewer: Enter with G

Graph settings: Space with Dots 3-5

Export content: Backspace with E

Disable expression: Backspace with L

Delete expression: Backspace with Dots 2-3-5-6

Delete All expressions: Backspace with Dots 3-5-6

Information about a disputed expression: Space with I

Zoom in on a graph: Plus (+) button

Zoom out on a graph: Minus (-) button

Pan around a graph: D-pads

Internet Browser: Ecosia

Open web page: Enter with O

Forward: Backspace with F

Back: Space with E or the Back button

Reload page: Enter with R

Add or manage bookmark: Enter with M

Bookmarks: Enter with dots 2-3-5

History: Enter with dots 2-3-6

New tab: Backspace with N

Previous tab: Backspace with K

Next tab: Backspace with dots 4-6

Close tab: Enter with C

Find: Space with F

Find next: Space with N

Find previous: Space with P

Downloads: Backspace with D

Ecosia menu: Space with W

Html Content Navigation (webviews)

To navigate backwards, add dots 7 and 8

Button: B

Control: C

ARIA landmark: D

Editable field: E

Focusable item: F

Graphic: G

Next graphic: G

Heading: H

Heading level 1: DOT 1

Heading level 2: DOT 2

Heading level 3: DOT 3

Heading level 4: DOT 4

Heading level 5: DOT 5

Heading level 6: DOT 6

List: O

List item: I

Link: L

Table: T

Checkbox: X

Combo box: Z

List of available webview commands: Space with H