

Prepping Zero Skis

Equipment Needed

- 80 grit sandpaper / 120 grit sandpaper
- Skin Care (spray)
- Nylon Brush
- Hot/Liquid Glide Wax (wax of the day) - Red or Yellow
 - Liquid topcoat if needed (Swix TS8)

Kick Zone (rubber)

1. Use 80 grit sandpaper to roughen up kick zone area
 - a. Be careful not to scrub out of the rubber zone
 - b. Use a small circular motion up the kick zone
 - c. Follow up with a small back and forth motion
2. Use 120 grit sandpaper at the beginning and end of kick zones
 - a. 5-10cm
 - b. Scrub lightly back and forth over area
3. Spray skin care onto rubber zone and rub in by hand
4. Use nylon brush to scrub zone

Glide Zone

1. Wax normally - Apply wax w/ wintersteiger
 - a. Let cool for 10-20min, then scrape & brush

Prepping Zero Skis