


Quick Reference Guide

(Zoom H6)

- Connect:
 - Insert 4 AA alkaline batteries.
 - Connect microphone(s) to H6 through a XLR cable, with shotgun mic usually to the 1st-Track (top left).
 - Connect your headphone (must be 35mm headphone jack, otherwise must use converter to switch to 35mm). Insert Splitter for 2 headphones if needed.
- Prepare to record.
 - The power switch is located on the bottom left. Hold down the power switch until you see the greeting page.
 - Insert SD card with up to 128GB. (Gently open the SD Card slot by using a key or a screwdriver.
 - **Format the SD Card**
 - Go to **Menu** (Right side button), and scroll down to **SD Card icon** by using the scrolling wheel right above the menu button.
 - Once you see the **SD Card icon (image at the bottom)**, select it by pressing down the scrolling wheel.
 - Select **Format**
 - Phantom Power
 - Go to **Menu**, under the **microphone icon (image at the bottom)**, select **Phantom**
 - Select On/Off and choose the Track(s) you would like to have Phantom Power.
 - Select Voltage according to your Microphone (12V, 24V, or 48V)
 - Record Format
 - Go to **Menu**, under the **STOP (red dot)** icon, select the format that is needed.
 - Choose WAV for better quality.
 - Higher bitrate, bigger file, better quality. Same to the frequency.



- Record
 - Select the Track Number(s)
 - Ex. if you insert microphone to **Track 1**, press **#1** until you see the **red light** on.
 - Press record button (big button with a dot) to record.



- Use wheels to adjust the gain on the volume.
 - Use PAD (0, -20) according to the environment
 - Use (-20) for outdoor/noisy environment.
 - Avoid audio peaking by looking at the **meter** on the screen.
 - To avoid clipping, keep the level **below -6db**.
 - If the audio clips, the **red light** will flicker above the Track number
- Playback and check
 - Press **▶||** to playback your audio files.
 - Use **◀◀▶▶** to navigate the library.

