Hand Timing Quick Start

Start of each run: Write the event and run details on printout e.g. “U12 WOMEN RUN 1” Use print button to advance paper Report the first forerunner’s time to Timing over the radio asap	
Enter next racer bib: Type bib number ➪ Number will be blinking top right Press green OK ➪ Number stops blinking	 
If You’re At The Start: Press green start to record a start time ➪ New line shows as C0 on display	
If You’re At The Finish: Press red stop to record a stop time ➪ New line shows as C1 on display	
Important Notes	**Be consistent** – try to hit the button the same way for each athlete **Do not miss a time** – It is more important to have the time recorded than to have the correct bib number

Troubleshooting

Entered wrong bib number, or didn’t finish entering next bib	Record time anyways If possible, write note that bib X was recorded as bib Y (on the printout or on a separate piece of paper)
Missed time	Write note that bib X was missed (on the printout or on a separate piece of paper)
Bib number is flashing	Press the green OK button 
I used **START** instead of **STOP** or **STOP** instead of **START**	That is ok. The unit recorded the time correctly and we can still use it if needed.
The screen doesn’t let me enter a bib number and it doesn’t seem to record times	If you see the text “Norm” above the F0 button, press F0. This will take you back into the correct mode. Otherwise, try pressing the menu button (white with lines across) twice.
Printer stopped working or out of paper	Continue entering times. We can print results from memory at the end of the race
New entries not showing on screen or Unit turns off	Let Start or Finish ref know. They should have spare batteries if needed.