# USER MANUAL



# LookCamPro

This manual describes how to use this WIFI camera and install the supplied software. Be sure that you have read and understood its contents before using the camera.

## To get started, you need:

1. A wireless network (only support 2.4G) ***Use numbers and letters in creating network name and password.**

2. A smart device, such as an Android Smart Phone or Tablet (Android version 6.0 or latest) or an iPhone, iPad, or iPod Touch (IOS version 8.0 or latest).

**AI**  **l:**

**LookCamPro QR Code**

Download the App “LookCamPro” from Google Play Store (for Android) or Apple Store (for iOS). Or scan the QR code to download the APP.


## s to add devices on Phone :

①

②

③

**IP mode setting for new device**



# Add an Online device (IP Mode)



## AP mode setting for new device


***AP mode for point to point , the camera can not be view remotely . the phone need to be close to the camera to be able to view the live videos. **

## Way ①

### ***Camera configured**


Before setting, connecting the device with power supply and turn it on.

Open the “LookCamPro” App , Click + to add a new device ,when using the camera for the first time please select the “Mode 1” .


Camera
BACK
Add Camera
or
Mode 1
Mode 2
Mode 3
Add new camera
Camera
Photo
Video
Playback

Click “Go to WIFI configuration” to connect the network same as camera’s UID（which is unique to each unit).

***If there is no hotspot WIFI please reset the camera and wait the camera reboot**


BACK
Connected devices
Internet may not be available
Switch to mobile data
Another network
Current network
Available networks
23E
TPGuest_55CF
ChinaNet-X5br
TP-LINK_17D1
TP-LINK_55CF
ChinaNet-Ki5J
Go to WiFi configuration

***If your Android system phone show you that "the current WLAN network cannot access the internet . Switch to another network ?" Just ignore it. **


Back to  LookCamPro APP after connection is successful.



Click “ WIRELESS ACCES POINTS” to find out your router WIFI .


Select your home’s 2.4Ghz WI-FI signal and enter the correct password. Confirm the password and connect. Then click “done”. The camera will reboot. It takes about 2-5 minutes, then the camera will show online.






***If the camera show “connection timeout”, That means Wi-Fi password is wrong . Please reset the camera ,and connect again.**

Big/Samll view LAN search





ud ( alarm event )

al images Local



Multiple screen


BACK
Camera
Video
Photo
Hold to talk
Audio
More

Upside/Down

Left/Right Indicator Led ON/OFF Night Vision ON/OFF

Resolution Rate Video Record Snapshot

Microphone Speaker

More


Larger Screen
Menu setting


## Way ②

### ***Camera configured**

The camera must be already connected to a network (IP Mode).

Open the “LookCamPro” App , Click + and please select the “Mode 2” to add a new online device






or



Input the UID number ( you also can scan the camera QR Code to get the UID number ), then input new password if changed. The default password is 6666.




or




***If you forgot your new password , you could reset the device and set the IP Mode again.**

## Way ③


### ***Camera configured**

Before setting, connecting the device with power supply and turn it on.

Open the “LookCamPro” App , Click + and please select the “Mode 3” to add a new device




or





Click “Go to WIFI configuration” to connect the network same as camera’s UID（which is unique to each unit).


BACK
Connected devices
Internet may not be available
Switch to mobile data
Another network
Current network
TUT-000010-MKKTM
Available networks
23E
TPGuest_55CF
ChinaNet-XSbr
TP-LINK_17D1
TP-LINK_55CF
ChinaNet-KiSJ
Go to WiFi configuration

***If there is no hotspot WIFI please reset the camera and wait the camera reboot**

****If your Android system phone show you that "the current WLAN network cannot access the internet . Switch to another network ?" Just ignore it. ***

Back to LookCamPro APP after connection is successful.



If the camera show "disconnected ", click UID number to refresh the state .

Click “ Cancel” to stay in AP Mode.

***AP mode for point to point , the camera can not be view remotely . the phone need to be close to the camera ( less than 10 meters) to be able to view the live videos**

## FREQUENTLY ASKED QUESTIONS

What Micro SD Card is required for recording?

Why can’t I use my Micro SD Card for recording?

The camera supports up to 128 GB Micro SD card. Please use High Speed Class 10 FAT formatted memory card. You must format the Micro SD before using. If SD card is not recognized when inserted into camera, just remove and re-insert.

## Why can’t the camera go online?

1. Powerless.
2. Check if your router is working properly or not.
3. Weak Wi-Fi signal.
4. Wrong password wrong while Wi-Fi setting

Why is remote monitoring not smooth? You should choose a suitable resolution to watch according to your internet speed.

How could i save in SD card? Open the setting menu to set the SD card video recording.

Why i can't save to my SD card? SD Card must be formatted if this is your first time to use it .

How do I when I forgot my password? Press reset key for 10 seconds and restore the factory setting.

Disclaimer:

Our company would not be responsible to any consequences cause by improper use, please use it in appoint environment and comply with the relevant laws and regulations!