

	Technology	Module Speed (MT/s)	Clock Cycle Time (ns)	CAS Latency (CL)	Input "what if" Clock Cycle Here	Clock Cycle Time * # of Cycles = Total Completion Time
Examples-->						
	SDR	100	8.00	3	3	24 ns
	SDR	133	7.50	3	3	22.5 ns
	DDR	335	6.00	2.5	2.5	15 ns
	DDR	400	5.00	3	3	15 ns
	DDR2	667	3.00	5	5	15 ns
	DDR2	800	2.50	6	6	15 ns
	DDR3	1333	1.50	9	9	13.5 ns
	DDR3	1608	1.25	11	11	13.75 ns
	DDR4	1866	1.07	13	13	13.91 ns
	DDR4	2133	0.94	15	15	14.1 ns
	DDR4	2400	0.83	17	17	14.11 ns
	DDR4	2666	0.75	18	18	13.5 ns
	Just save-as this spreadsheet as your own; can't have nice things.					
	Your Memory (input here)					
	Speed (e.g. 2400, 2666, etc):	2666	15	15	15	35
	Desired Speed	2933	16.50225056	16.50225056	16.50225056	38.50525131
		3200	18.00450113	18.00450113	18.00450113	42.01050263
	You might want to protect these cells too...					
	(*~::~*)					